

Quick Start Guide



SNAP ANPR Processor

- Model 5310 1-Lane (Kit Processor)
- Model 5311 1-Lane Network
- Model 5312 2-Lane Network
- Model 5313 3-Lane Network
- Model 5314 4-Lane Network

About this Guide

This guide is intended for installation and commissioning engineers who are familiar with SNAP ANPR processors. It covers the initial setup of the complete range of rack mount ANPR processors but much of the content also applies to ANPR processors which are based on standard PC architecture.

Safety Notices Used In This Manual

Important! - Indicates a potential hazard that could seriously damage the equipment or endanger the engineer or subsequent user. Do not proceed beyond these notices until you have fully understood the implications.

Legal Notice

Camera surveillance is prohibited by law in some countries. Check the laws in your local region before using ANPR cameras and associated equipment.

Liability

Every care has been taken in the preparation of this manual. Please inform Videofit of any inaccuracies or omissions. Videofit cannot be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice. Videofit makes no warranty of any kind with regard to the material contained within this document, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Videofit shall not be liable nor responsible for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Trademark Acknowledgments

Internet Explorer, Microsoft and Windows are registered trademarks of the respective holders.

SNAP ANPR is a registered trademark of Videofit Limited.

Support

Should you require any technical assistance, please contact your SNAP ANPR reseller.

1. Description

These SNAP ANPR processors will recognise and log vehicle number plates from live ANPR camera video feeds. The processors feature a wide range of interfaces which enable specific actions to be taken based on whether the vehicle is known to the system; these include opening vehicle barriers or gates, displaying custom messages on driver feedback signs or raising alerts.

The processors are available in 1, 2, 3, and 4-lane versions and all feature networking as standard, apart from model 5310 which is supplied as part of the Kit product. However, all models can be upgraded in the field without restriction and without the need for any additional hardware.

2. Installing the Processor

These units are intended for rack mounting but may also free-stand. The rack mount handles may be removed for free-standing use.



VGA Monitor

Choose a location where the various cables can be easily managed. If using the VGA output, the unit will need to be close to the display unless you are intending to use a VGA extender. Similarly, the USB keyboard must also be adjacent to the processor unless third party extenders are used.

Important!

The processor must be used with the supplied mains adaptor. Use of any other power supply may damage the unit or lead to unreliable operation.

3. Set Up

To start the processor, momentarily press the *Start* button on the rear panel. The unit will take 2-3 seconds before the front panel indicators light up - this is normal. Do not repeatedly press the rear *Start* button or hold it down continuously.

The initialisation process will take a minute before the *Main Screen* appears and unit is ready for use. All processors are factory set with lane 1 pre-configured. This means that you just need to connect an ANPR camera to the *Lane 1 ANPR* BNC input on the rear panel in order for vehicles to be automatically recognised and appear on the *Main Screen*.

The main reason for vehicles not be recognised at this stage is due to poor camera set up. The golden rules are:-

- (i) Always view vehicles from the front.
- (ii) Ensure the number plates are large enough. The width of the vehicle should fill the frame (see image below left).
- (iii) Ensure number plates are fairly level (horizontal) within the image.
- (iv) Set the camera exposure for the reflective number plate, not the general scene (which will typically be very dark).



Perfect ANPR Image



Poor ANPR Image

4. Logging On

Before you can change any settings you will need to log on. On first use, the only account available will be the engineer's account. A sticker showing the default username and password is affixed to the bag containing this manual.

To log on, press the *Log On* toolbar button on the top left of the *Main Screen* (or press F2). The log on screen appears:-


A screenshot of a 'User Log On' dialog box. The dialog has a blue title bar with a small user icon and the text 'User Log On'. The main area is light blue and contains two text input fields: 'Log On Name' and 'Password'. To the right of the 'Log On Name' field is a small icon of a person in a blue uniform. At the bottom of the dialog are three buttons: 'Help', 'Cancel', and 'OK'.

Log On Screen

The engineer's account has unrestricted access to all areas, including diagnostics. This password should not be provided to the end user – instead, the commissioning engineer should create at least one Administrator account for the end user.

5. Adding Further Users

To add an additional user account, first ensure you are logged-on and then choose the *Settings* toolbar button at the top of the *Main Screen*.



Add User Account

Press the *Add User* button and follow the on-screen instructions. Note that you are only able to add users with a lower account access than your own – this means that any account may be created when logged on as an engineer.

6. Configuring Additional Cameras

Each processor can accept up to 4 ANPR cameras and each of these four lanes may also have up to 3 overview cameras. The total number of possible video inputs is therefore 16.

Note that not all of the lanes may be available depending on the processor model.

ANPR cameras are designed to read highly reflective number plates and this usually results in a very dark image (see below left). It is often desirable, however, to record one or more high quality colour overview images of each recognised vehicle to aid identification (below right).



Typical ANPR Image




Typical Overview Image

Eight BNC input connectors are provided on the rear of the processor. These are for the ANPR cameras (4 lanes) and one colour overview camera per lane. The remaining 8 overview cameras can be accessed using the optional Overview Expander (part 3730).

Although lane 1 is pre-configured, if you wish to add further ANPR or overview cameras you will need to configure them (see opposite).

6. Configuring Additional Cameras (continued)

To add additional cameras, first ensure you are logged-on with either the engineer or an administrator account and then choose the *Admin* toolbar button at the top right of the *Main Screen*. Then choose the *Install Cameras* tab:




Add Cameras

Up to 16 cameras (4 lanes) may be displayed in the above form depending on the model. For each lane there is a single ANPR camera and 3 overview cameras. Tick only those cameras you wish to use.

If you wish to view the live video of any input, select the camera from the list and press the *Adjust Camera Image* button.

7. Known Vehicle Database

One of the main benefits of an ANPR system is the ability to take various actions based on whether the vehicle is known. Allowing known vehicles to have automatic access to a site or raising automatic alerts for suspect vehicles are common requirements.



Database Screen

Known vehicles are entered in the *Database* screen. To display this window, choose the *Database* toolbar button at the top of the *Main Screen*.

8. Adding Vehicles to the Database

To manually add a new vehicle, press the *New* button in the bottom right hand corner of the screen. The minimum information you will need to enter are the vehicle registration and the group, although there is a wide variety of additional information that may also be entered.


It is the group which determines whether a vehicle will be allowed entry through a particular barrier as well as the content of the LED Sign message, alerts and offences. You should therefore group vehicles (staff, contractors, deliveries, etc) to allow you to control access by a simple modification to the group settings (see next section).

9. Additional Database Groups

There are almost 1,000 groups available for you to use. Groups 1 and 2 are preset as *Hotlist* and *Visitor* respectively and cannot be changed.

To add additional groups, ensure you are logged-on with sufficient access rights and choose the *Settings* toolbar at the top of the *Main Screen*. Then choose the *Database* tab.


The actions for each group are configured by choosing the *Group Settings* button (see next section).



Database Settings Screen

10. Group Settings

Here you can name each group, apart from groups 1 & 2 which are fixed. Use the *Group Expiry Setting* if you wish the vehicles to have only a limited period of access (the time period commences when that vehicle is added to the database). This is useful for custom visitor groups, for example, such as *Visitor 8 Hour* or *Contractor 30 Day*.




Adding Database Groups

11. Barrier Control & LED Sign Messages

Now that you have set up your groups you can configure which groups are allowed to open which barriers and also apply a time schedule, if required.

Choose the *Define Schedule* button from the *Database Settings* screen to display the scheduled group actions:-



Group Actions & Time Schedules

There are 8 schedules available for you to use, but please ensure you press the *Apply* button to save your settings before changing schedules.

Select the camera(s) and group(s) you wish to manage and then choose the required action for the blue and yellow periods shown on the weekly grid. You can change the blue and yellow periods by dragging with the mouse across the grid.

Note the second message sign entry box will be enabled only if a two-line sign has previously been configured (located at Admin> Engineer>Sign/Serial/Text).

12. Networking

If you wish to create a network ANPR system then, as a first step, give each processor a unique processor number. This can be found on the *Engineer* tab in *Admin*.

Then choose *Capture* or *Manager* as required and press the *Network Setup* button (see below). Here you will need to add each processor that needs to communicate with this processor, together with the associated IP address.

The screenshot shows the 'Administration' window with the 'Engineer' tab selected. The 'Processor Identification' section contains three text input fields: 'Organisation or Company Name' (value: not set), 'Site Name' (value: not set), and 'Computer Name' (value: not set). To the right, there are two numeric input fields: 'Processor' (value: 1) and 'Site Number' (value: 1). The 'Networking' section has three radio buttons: 'None' (unchecked), 'Capture' (checked), and 'Manager' (unchecked). A 'Network Setup' button is located below the radio buttons. Below the 'Networking' section, there is a 'Set maximum stay and non-return times for this site' label and an 'Offences Setup' button. At the bottom of the window, there are 'Help' and 'OK' buttons.

Administration

Install Cameras Recognition Settings Recognition Records

Site Configuration Security System Records Engineer

Processor Identification

Organisation or Company Name Processor
not set 1

Site Name Site Number
not set 1

Computer Name
not set

Networking

None: This is a stand-alone video capture processor with cameras
 Capture: This is a networked video capture processor with cameras
 Manager: This is a network manager receiving records from capture

Network Setup

Set maximum stay and non-return times for this site Offences Setup

Guide
Please identify this processor and its location using suitable names
These identifiers are used in many printed records
A unique name is desirable if this processor is networked

Help OK

Network Set Up

12. Networking (continued)

When creating a network system, the following settings will need to be configured:-

- User accounts (Capture & Manager)
- Camera Names (Capture & Manager)
- Group Names (Capture & Manager)
- Graphical Reports (Capture & Manager)
- Alerts (Capture & Manager)
- Schedules & Actions (Capture)
- Recognition Settings (Capture)

If required, Auto-correction would normally only be enabled on the capture processors and should be disabled at the Manager(s).

13. Troubleshooting

Vehicles Not Captured

If the system is not recognising vehicles, park a vehicle at the intended capture point and click the associated camera on the *Main Screen* to check the live image. The plate should have good contrast, be reasonably level in the picture and should be large enough to be read (a standard rectangular plate will be around a quarter of the total image width).

Remember that there is a setting which determines when the same plate is allowed to be captured again – the default setting (10 secs) may be changed by navigating to *Admin>Recognition Settings* from the *Main Screen*. Note that there is a separate setting for each ANPR camera.

Barrier Not Opening

If the barrier or gate is not opening for a vehicle, check the following:-

- (i) Ensure the plate has been read correctly
- (ii) Check the vehicle is in the correct group in the Database
- (iii) Ensure that the group is correctly set to open the barrier for that group, by that camera at that time of day/day of week.

Databases Not Synchronised

For a networked system, any database updates performed at the Manager should automatically appear at the capture processor. If this does not happen, check for connectivity between all processors and that all firewalls are enabled in both directions.

End

Revision 4
Copyright © Videofit Limited 2016

Videofit Limited
Cheltenham
England

www.snapanpr.co.uk